CD Lens Cleaning System



Removes performance impairing debris



Safely removes performance impairing debris (dust, dirt, smoke residue) which can accumulate on the optical lens of a CD player or drive. Easy-to-use "On-Disc" voice instructions explain the cleaning process while precision-engineered lens cleaning brushes wipe dust off the lens. Regular use can restore performance to a lens impaired by contamination.

System consists of:

- CD Lens Cleaner
- Storage case
- Instructions for use

Order # 105987-1 Case pack 10 per shipper

CD Lens Cleaning System

- Safely removes performance impairing contamination from lens
- Compatible with all CDs players & drives
- Ensures maximum performance and extends equipment life



PerfectData[®]

110 West Easy Street • Simi Valley, California 93065 • Tel: 1-800-9 Perfect • 805-581-4000 • Fax: 805-522-5788 Visit our web site: www.perfectdata.com • E-Mail: perfc@aol.com